

Log sounder Interface firmware development

- V1.7 NO COMPATIBLE PROCESSOR
 - Improving the functioning of the depth finder in the small waters
 - Manual setting of the depth finder blanking to avoid keel echo.

- V2.0 PROCESSOR COMPATIBLE
 - When a Processor is functioning on the Topline bus, only the depth channel is displayed.
 - When a Processor is functioning on the Topline bus, connect directly on the ILS one starboard Ultrasonic speedo sensor (see specifics firmwares for this sensor).
 - Without PROCESSOR, the functioning is the same as the previous version.

- V2.1 PROCESSOR COMPATIBLE
 - Change to keep in memory the 'speed over ground' option after initialization.