BOX Wi-Fi

Product part number: 90-60-508-002

MARINE	ELECTRONICS Int
Init	WiFi O NMEA In O NMEA Out O TOPLINE O
NME	Box WiFi A & Topline Bus

USER MANUAL AND INSTALLATION GUIDE



Zi de Kerandré – Rue Gutemberg – 56700 – HENNEBONT – FRANCE www.nke-marine-electronics.com



+33 297 365 685

1.	INTRODUCTION	3
2.	NMEA INPUT	3
3.	WIRED NMEA OUTPUT	5
4.	WI-FI CONNECTION	7
5.	PARAMETRAGE AVEC UN MULTIGRAPHIC	7
6.	STATUS INDICATORS	9
7.	USING THE « INIT » KEY	9
8.	INSTALLATION	11
L E N C	IST OF ACCESSORIES BEFORE INSTALLATION AOUNTING THE <i>BOX WIFI</i> CONNECTION TO THE <i>TOPLINE BUS</i> <i>IMEA INPUT SETUP</i> ETUP PROCEDURE	
5		
9.	SET A WIFI CONNECTION TO A SMARTPHONE	13
9. 10.	SET A WIFI CONNECTION TO A SMARTPHONE TECHNICAL SPECIFICATIONS	13 15

1. INTRODUCTION

The *nke Wifi Box* is a NMEA/Topline multiplexer which allows the Topline Bus and NMEA instruments to connect to a PC or any wireless compatible device.

The **nke Wifi Box** features a NMEA0183 wired and wireless input to receive AIS data or any other data coming from a NMEA0183 source. It is a communication bridge that converts NMEA data to **Topline** channels to make information available to display on your **Topline** system: repeaters, Gyropilot...

The *nke Wifi Box* also features NMEA0183 wired and wireless output multiplexing Topline and NMEA data for interfacing with a PC or any wireless compatible device.

2. NMEA INPUT

The *nke Wifi Box* can process NMEA data format through the wire input and/or Wifi wireless connection.

The *nke Box Wi-Fi* identifies the sentences coming from an AIS receiver or any NMEA 183 source.

An auto baud rate detection algorithm allows reception of AIS and NMEA data at 4800, 9600, 19200, or 38400 bauds. The baud rate is saved in the memory once 10 correct NMEA sentences have been received.

The AIS data flow received via the NMEA input is sent directly to the *Wifi* connection and the NMEA 183 output.

Data coming from the NMEA 183 device is sent once the set up procedure has been completed on the Topline bus.

WARNING

Topline channels have priority: a NMEA 183 channel is not considered if an equivalent channel is already available on the Topline bus.

Once the instrument connected to the NMEA 183 input stops transmitting data the last values are displayed for 64 seconds on the Topline screens.

The NMEA input has **priority** on the Wifi NMEA connection.

	Created channels	NME	A sentences ι	ised
N°	Label	Priority 1	Priority 2	Priority 3
1	F_SPEEDO	VHW		
2	HEADING MAGNETIC	HDG	VHW	HDM
3	HEADING TRUE	HDT	VHW	
4	DEPTH	DPT	DBT	

5	MINSEC	ZDA	RMC	
6	TOTAL LOG	VLW		
7	TRIP LOG	VLW		
8	HOURS DAY	ZDA	RMC	
9	AIR TEMPERATURE	MTA	XDR	
10	WATER TEMPERATURE	MTW		
11	BAROMETER	MMB	XDR	
12	SPEEDO	VHW		
13	APPARENT WIND SPEED	MWV	VWR	
14	APPARENT WIND ANGLE	MWV	VWR	
15	DISTANCE TO WPT	BWC	RMB	
16	BEARING TO WPT (True)	BWC	RMB	
17	CROSS TRACK ERROR	APB	RMB	XTE
18	SPEED OVER GROUND	VTG	RMC	
19	COURSE OVER GROUND (True)	VTG	RMC	
20	FORESTAY LOAD	XDR		
21	BEARING ORIGIN TO DESTINATION	APA	APB	
22	B_PILOT	APA	APB	XTE
23	YEAR MONTH	ZDA	RMC	
24	F_HEADING	HDG	VHW	HDM
25	F_APPARENT WIND ANGLE	MWV	VWR	
26	LAT_DEGMIN	GGA	GLL	RMC
27	LAT_MILMIN	GGA	GLL	RMC
28	LON_DEGMIN	GGA	GLL	RMC
29	LON_MILMIN	GGA	GLL	RMC
30	SPEED TO WP	WCV		
31	TARGET SPEED	KEP		
32	NEXT TACK HEADING	KEP		
33	OPTIMUM TWA	KEP		
34	TARGET VMG	KEP		
35	POLAR SPEED	KEP		
36	CMG OPTIMUM ANGLE	KEP		
37	VMG OPTIMUM ANGLE	KEP		
38	TARGET CMG	KEP		
39	TARGET VMG	KEP		

40	CURRENT DIRECTION	KEP	VDR	
41	CURRENT SPEED	KEP	VDR	
42	ATMOSPHERIC PRESSURE	MMB	XDR	
43	DECLINAISON	RMC		
44	WAYPOINT IDENTIFICATION	RMB	BWC	
45	DYNAMICS1	PNKEA,,1		
46	DYNAMICS2	PNKEA,,2		
47	DYNAMICS3	PNKEA,,3		
48	DYNAMICS4	PNKEA,,4		
49	DYNAMICS5	PNKEA,,5		
50	DYNAMICS6	PNKEA,,6		
51	DYNAMICS7	PNKEA,,7		
52	DYNAMICS8	PNKEA,,8		

3. WIRED NMEA OUTPUT

The NMEA 183 wired output is set to 38400 bauds by default and sends AIS data from the NMEA 183 input and Topline data converted to NMEA standard sentences to instruments from other manufacturers. This NMEA output baud rate can be set up to 4800, 9600, 19200, 38400, 57600 through the Toplink utility software. The following settings are available via function 10 "Baudrate NMEA OUT": 51712 = 4800 bauds 51713 = 9600 bauds 51714 = 19200 bauds 51715 = 38400 bauds 51716 = 57600 bauds

The following data is converted and sent via NMEA 183, depending on the relevant sensors being connected to the *TOPLINE* bus:

Canaux Topline	XDR	RSA	DBT	DPT	VLW	WHV	MWV	WR	VWT	DWM	MTW	MMB	HDG	MDM	HDT	VTG	ZDA	GLL	XTE	RMB	RMC	PNKEP,01	PNKEP,02	PNKEP,03	PNKEP,04	PNKEP,05	CUR	WPL
MAST ANGLE	X																											
RUDDER ANGLE		X																										
DEPHT			X	X																								
TRIP LOG					X																							

TOTAL LOG				X																					
SPEEDO					x																				
MAGNETIC HEADING					x																				
TRUE HEADING					x								x												
CORRECTED AWA MAST ANGLE						x	х																		
AWA						x	х																		
AWS						х	х																		
TWA						x		х																	
TWS						x		х	х																
TWD									х																
AIR TEMPERATURE	x																								
WATER TEMPERATURE										x															
ATMOSPHERIC PRESSURE											x														
BAROMETER			ĺ							İ	X	İ													
COMPASS						İ						X	X												
CAP OVER GROUND														x					x						
SPEED OVER GROUND														x					x						
YEAR MONTH															X				Х						
HOUR DAY															х				Х						
MINSEC															X				Х						
LAT_DEGMIN																х			х						
LAT_MILMIN																Х			Х						
LON_DEGMIN																Х			Х						
LON_MILMIN																Х			Х						
CROSS TRACK ERROR																	х	x							
DISTANCE TO WP																		X							
BEARING TO WP																		Х							
MAGNETIC DEVIATION																			х						
HEEL	X																								
PITCH	X																								
TARGET SPEED																				X					
NEXT TACK HEADING																					х				
OPTIMUM WIND ANGLE																						x			
TARGET VMG				Ì		İ																X			
TARGET POLAR				1								İ										x			
CMG OPTIMUM ANGLE																							x		
TARGET CMG																							X		
VMG OPTIMUM ANGLE																							х		

TARGET VMG													Х			
CURRENT DIRECTION														x	x	
CURRENT SPEED														X	X	
MAN OVER BOARD																х

4. WI-FI CONNECTION

The *WiFi* transmits the AIS data and the NMEA sentences coming from the NMEA input as well as the NMEA data from the Topline bus. It can also forward NMEA data (i.e. bearing and distance to waypoint) to the Topline bus (providing the relevant channels are available) and to the NMEA output.

The *nke Box Wi-Fi* creates a wireless access point 802.11b+g with the following parameters:

- SSID : NKE-xxxxxx
- WPA : 21xxxxxxxxx (matching the serial number featured on the *WiFi Box* label sticked on the side of the box)
- IP address: 192.168.56.1
- Port : 50000
- TCP + UDP protocol

TCP is a communication protocol which is based on connection with delivery validation and limits the use to one only host while UDP uses a simple transmission model allowing communication with several hosts simultaneously.

A DHCP server can connect up to 7 hosts simultaneously.

Data transmitted in NMEA 0183 format is identical to the data output via the wire interface (see §3).

5. SET UP FROM A MULTIGRAPHIC DISPLAY

If your *nke Wifi Box* is connected to a Topline Bus featuring a Multigraphic (from V2.0), the SSID and WiFi channel can be modified.



Modification of the SSID from a Multigraphic:

Modification of the WiFi channel from a Multigraphic:

|

A selection is offered between "Auto" and 13 channels. The default setting is "Auto" (automatic).



6. STATUS INDICATORS

	CTRONICS Int WIFI O NMEA In NMEA Out TOPLINE	Status indicators
NMEA & T	Box WiFi	

5 status indicators show the operation status of the **Box Wi-Fi**.

Init	Press the Init key
	Key press acknowledgement, audible signal
Wi-Fi	Wifi transmit
	Wifi reception
NMEA In	Off: no data coming in the NMEA port
	Flashes after each valid NMEA sentence received
	Flashes after each non-valid NMEA sentence received
NMEA Out	Flashes after each valid NMEA sentence sent on the wired NMEA port
TOPLINE	Flashes quickly if its Topline address is <> 0
	Flashes quickly if its Topline address is 0
	Fix light: data bus Topline wire is disconnected or «no master »
	Flashes every second: interface's address is 0 and data bus Topline wire is disconnected or «no master »

7. USING THE « INIT » KEY

|

 Press and hold 1 sec to display the number of connected devices, up to 5. 1 device is indicated by the « Topline » led lighting red, 2 devices by the « Topline » and « NMEA Out », 3 devices by the « Topline + NMEA Out + NMEA In », 4 devices by « Topline + NMEA Out + NMEA In + Wifi » and 5 devices by all led indicators in red.

- Press and hold 3 sec followed by OFF and ON to reset all NMEA interfaces.
- Press and hold 3 sec will initialise the NMEA input (wire and WiFi), listen to NMEA sentences for 10 seconds, and then create list and nodes for the Topline bus (only slave).
- Press and hold 6 sec will launch a second NMEA initialisation, and add NMEA channels without overwriting the existing table. With this function, you can add NMEA channels coming from the WiFi connection without editing the configuration of the wired NMEA input.
- Press and hold 9 sec to perform a full reset and return to factory settings.

8. INSTALLATION

List of accessories

- TOPLINE junction box with NMEA connection: 90-60-417

Before installation

The **Box WiFi** is protected from water splashing. It must be mounted in a location where there is no risk of submersion.

Mounting the Box WiFi

Use Ø4mm screws



WARNING:

- The connection of the *nke Box Wi-Fi* must be carried out before power to the unit is switched on.

Connection to the *Topline Bus*

- 1. Run the *nke Box Wi-Fi* cable to the *TOPLINE* junction box in your system.
- 2. Connect the bus cable in the junction box.
- 3. Connect the NMEA+ and NMEA- wires to your NMEA 183 device or AIS receiver.



Should you need to shorten the bus cable, uncover and tin the wires before connecting in the junction box.

Wire colour codes

5 wire white cable	ldent	ification
white	+12V	_
black	Data Topline	TOPLINE bus
braid	ground	
red	NME	A output
yellow	NMEA +	
green	NMEA –	NMEA input

NMEA input setup



WARNING

The NMEA data coming from an AIS receiver does not need NMEA input calibration. It will be directly echoed on the Wi-Fi and wired NMEA outputs.

The NMEA input must be set-up to identify and save the NMEA sentences received from the connected instruments (GPS, PC, etc...). NMEA channels are created and

saved in the *nke Box Wi-Fi* memory. They will remain on the *Topline* bus each time the system is turned on.

Setup procedure

- Ensure that the NMEA 183 connected instrument sends data and press *INIT* until you hear 3 beeps.
- The NMEA 183 input port will scan for NMEA 183 data. This is acknowledged by audible signals over 10 seconds and a long signal once the scan is completed.
- Once the scan search is completed the unit will sound one signal per channel which has been created on the Topline bus.



WARNING

If there is no NMEA data coming in, this procedure gives a slave address to the **nke Box Wi-Fi**. In this case, the Interface is considered as a slave unit by the "master" display.

9. SET A WIFI CONNECTION TO A SMARTPHONE

Connect the device to the *WiFi Box* network and use the data coming from your Topline bus.

Activate the WiFi function on your Smartphone:







l

WARNING

If your device is using a firewall, check and make sure "Port 50000" is available.

10. TECHNICAL SPECIFICATIONS

Description	Values
Dimensions	110x56.4x26mm (length x height x depth)
Weight	20g with a 3m cable (32g/m)
Power supply	8V – 32V DC
Current consumption at 12V	50 mA
NMEA input	NMEA 183, automatic baud rate configuration from 4800 to 38400 bauds. Direct reading of AIS data without input setup.
NMEA wired output	NMEA0183 @ 38400 bauds, can be set up with the Toplink utility software at: 4800, 9600, 19200, 57600 bauds
Wi-Fi connection	Wi-Fi 802.11b+g
	SSID:NKE-xxxxxx
	IP address: 192.168.56.1
	Port: 50000
	Protocol: TCP + UDP
Environment	IP54 protection (against dust and water splashing)
	Storage temperature: -20°C to +60°C
	Operating temperature: -10°C to +50°C
Power cable	Ø5,5mm, 4 wires + ground, 3m long.

11. DIAGRAMME DE FLUX



Connection examples:

1. I want to use a single input port on my PC to receive data from the AIS and the Topline.

I send AIS data to the NMEA input with default setup. The Wifi Box is connected to the Topline system. Both AIS and Topline data will be available from the NMEA wired output in NMEA format.

2. I want to receive Topline and AIS data on my tablet PC.

I send AIS data to the NMEA input with default setup. The Wifi Box is connected to the Topline system. Both AIS and Topline data will be available from the WiFi output in NMEA format (refer to §9 for WiFi connections).

3. I want to connect my tablet to a system configured in the same way as in case 1 and use the WiFi in/out.

I set up the WiFi connection on my tablet (refer to §9 for WiFi connection), from my tablet I select the data to display and then initialise the NMEA input on the WiFi Box (press and hold INI key for 3 seconds – refer to §8).

4. I have a Maxsea application on my PC with a wired connection to the WiFi Box and I want to use Adrena to send Performance channels.

I connect my PC to the WiFi (refer to §9 for WiFi connection to PC), I set up ADRENA (UDP link IN/OUT, port 5000) and then initialisethe NMEA input of the WiFi Box (press and hold INI key for 6 seconds, refer to §7)

Déclaration de conformité

Nous,

Nke marine electronics rue Gutenberg ZI de Kerandré 56700 HENNEBONT Tel : +33 297 365 685 Fax ; +33 297 364 674

Déclarons sous notre seule responsabilité que le produit

BOX WiFi

Auquel se réfère cette déclaration est en conformité avec les spécifications suivantes :

 Safety :
 EN 60950-1 :2006+A11 :2009+A1 :2010

 Health:
 EN 50371 :2002-03

 EMC :
 EN 301 489-1 V1.8.1 :2008-04, EN 301 489-17 V2.1.1 :2009-05

 Radio :
 EN 300 328 V1.7.1 :2006-10

 FCC Part 15C, FCC id : T9J-RN171

 IC : RSS-210

Le produit est conforme aux exigences de la directive CEM 89/336/CEE et porte en conséquence le marquage CE.

Hennebont

Jean Claude LE BLEIS

Cet appareil est conforme à la partie 15 des règles de la FCC. Son fonctionnement est soumis aux conditions suivantes : (1) ce dispositif ne peut pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent provoquer un fonctionnement indésirable.

